



見出	部品番号	部品名称	個数	型 寸	互換性	適用号機	備 考
NO.	PART NO.	PART NAME	Q'ty	DESCRIPTION	R/P	FROM ~ UP TO SERIAL NO.	REMARKS
S01	5321 140A 000	ロプスセット	1				号機連絡必要 Serial No. of machine required when ordering
1	5321 1401 000	バンパ	1				
2	K710 0110 020	Fボルト	10	M10×20			
3	A301 0110 003	ナット	4	M10			
4	5321 1403 000	ガード	1				
5	5321 1409 000	ブラケット	1				
6	5321 1411 000	ブラケット	1				
7	A054 0110 070	ボルト7T	4	M10×70			
8	F301 0110 000	Fナット	4	M10			
9	0350 0141 022	PW	4	10×22×2.3			
10	5321 1412 000	ガード	1				
11	A252 0780 016	トラスコネジ	6	M8×16			
12	5316 1423 000	ルーフ	1				
13	F301 0108 000	Fナット	6	M8			
14	3718 3512 000	シートベルト	1				
15	5321 1421 000	マーク	3				製造号機 Serial numbers of ROPS
16	5321 1422 000	マーク	1				ROPS宣言書 Certification of ROPS

注 1) S01 ROPS set (No.1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16を含む)にて供給。単品供給不可。  
ROPS製造号機 と 本機製造号機 を管理しています。  
ROPS set 注文の際には、本機製造号機を連絡願います。

Note 1) ROPS can only be supplied as a complete set. Individual parts ( No.1,2,3,4,5,6,7,8,9,10,11,12,13,14, 15,and 16 ) can not be supplied. ROPS set can not be supplied without serial number of the main machine.  
Please give the serial number of the main machine when ordering as the serial numbers of the ROPS and the main machine need to be controled together.