



見出 图片号码 NO.	部品番号 零件号码 PART NO.	部品名称	PART NAME	零件名称	個数 数量 Q'ty	型 寸 尺 寸 DESCRIPTION	互 換 性 R/P	適 用 号 機 適 用 机 型 FROM ~ UP TO SERIAL NO.	備 考 备 注 REMARKS
1	5332 8534 000	デフASSY	DIFF ASSY	差速器总装	1				
1-1	5332 8504 000	デフケース	CASE	箱体	1				
1-2	5332 8504 200	ハベルギヤ 15	GEAR 15	齿轮 15	2				
1-3	5332 8504 100	ハベルギヤ	GEAR 16	齿轮 16	2				
1-4	5332 8504 300	シャフト	SHAFT	轴	1				
1-5	0550 0003 020	スプリングピン	PIN SPRING	弹簧销	1	3×20			
2	5332 8531 000	シャフト	SHAFT	轴	1				
3	5332 8532 000	シャフト	SHAFT	轴	1				
4	5332 8503 000	ギヤ 27	GEAR 27	齿轮 27	1				
5	0750 0060 060	ハアリング	BEARING	轴承	1	6006			
6	0750 0063 060	ハアリング	BEARING	轴承	1	6306			