

消耗品リスト(List of Consumables and Spares)

～日文(英文)～

CMX2402HEH / CMX2402HEF / CMX2402HEFD

ユニット(UNIT)	項目	Item	部品番号(Part No)	交換インターバル	Schedule	個数(Qty)
Engine		Oil Filter Cartridge	15400-RTA-004		Initially 20 hrs. After - Every 200 hrs. Replace if defective.	1
		Air Filter Element	17210-Z6L-010		Every 200 hrs or seasonally.	1
			P821575 *1			
		Spark Plug (NGK BPR5ES)	98079-5587G		Clean: every 100 hrs. Every 300 hrs.	2
Fuel System		Hose (Carburetor - Fuel Pump)	16860-Z6L-000		Every 2 years.	1
		Hose (Fuel Pump - Fuel Filter)	16850-Z6L-020		Every 2 years.	1
		Hose (Fuel Filter - Fuel Cock)	35700557000		Every 2 years.	1
		Hose(Fuel Cock - Fuel Tank)	53320315001		Every 2 years.	1
Drive Train		V-belt (HST)	08521400036		Replace if defective.	1
		HST Oil Filter	53212071200		When HST oil is changed (2 years or every 300 hours).	1
Cutting System		Blade Set (Iai)	Z3324202010		Replace if defective.	1
Electrical System		Battery	37053901000		Replace if defective.	1

*1: indicates the cyclone air cleaner model.

CMX2402HCAS / CMX2402HFDA

ユニット(UNIT)	項目	Item	部品番号(Part No)	交換インターバル	Schedule	個数(Qty)
Engine		Oil Filter Cartridge	15400-RTA-004		Initially 20 hrs. After - Every 200 hrs. Replace if defective.	1
		Air Filter Element	17210-Z6L-010		Every 200 hrs or seasonally.	1
			P821575 *1			
		Spark Plug (NGK BPR5ES)	98079-5587G		Clean: every 100 hrs. Every 300 hrs.	2
Fuel System		Hose (Carburetor - Fuel Pump)	16860-Z6L-000		Every 2 years.	1
		Hose (Fuel Pump - Fuel Filter)	16850-Z6L-020		Every 2 years.	1
		Hose (Fuel Filter - Fuel Cock)	35700557000		Every 2 years.	1
		Hose(Fuel Cock - Fuel Tank)	53320315001		Every 2 years.	1
Drive Train		V-belt (HST)	08521400036		Replace if defective.	1
		HST Oil Filter	53212071200		When HST oil is changed (2 years or every 300 hours).	1
Cutting System		Blade Set (Iai)	Z3324202010		Replace if defective.	1
Electrical System		Battery	37053901000		Replace if defective.	1

*1: indicates the cyclone air cleaner model.

CMX2402HUSD

ユニット(UNIT)	項目	Item	部品番号(Part No)	交換インターバル	Schedule	個数(Qty)
Engine		Oil Filter Cartridge	15400-RTA-004		Initially 20 hrs. After - Every 200 hrs. Replace if defective.	1
		Air Filter Element	17210-Z6L-010		Every 200 hrs or seasonally.	1
			P821575 *1			
		Spark Plug (NGK ZFR5F)	98079-5587G		Clean: every 100 hrs. Every 300 hrs.	2
Fuel System		Hose (Carburator - Fuel Pump)	16860-Z6L-000		Every 2 years.	1
		Hose (Fuel Pump - Fuel Filter)	16850-Z6L-020		Every 2 years.	1
		Hose (Fuel Filter - Fuel Cock)	53620315000		Every 2 years.	1
		Hose(Fuel Cock - Fuel Tank)	53620314000		Every 2 years.	1
		Hose(Air Cleaner Case - Canister)	35700574000		Every 2 years.	1
		Hose(Canister - Joint)	35700574000		Every 2 years.	1
		Hose(Joint - Fuel Tank)	35700571000		Every 2 years.	1
Drive Train		V-belt (HST)	08521400036		Replace if defective.	1
		HST Oil Filter	53212071200		When HST oil is changed (2 years or every 300 hours).	1
Cutting System		Blade Set (Iai)	Z3324202010		Replace if defective.	1
Electrical System		Battery	37053901000		Replace if defective.	1

*1: indicates the cyclone air cleaner model.